

# STIEBEL ELTRON

## Condensation drain connection

Insert condensate drain hose into the S trap.

The tip of the hose should be approx 60mm below the water level.

This will eliminate the potential for odors to be drawn into the ventilation unit.

